



First table value (line 1) must be **0.00** for both **Height** and **Volume**, see below

Height: in Metres 1 metre = 100cm
Volume: (m³) 1 cubic metre = 1000 ltrs



The maximum number of lines that can be input/imported is 95 (including 0.00)



If 96 lines or more are input, the gauge will need to be returned to OLE for a reset and reload of firmware.
 (this can cause the gauge to display 0 Ltr, or display HIGH)